


## DSX20-RMTS/DSX20-LMTS/DSX20-TMTS ACCESSORIES


After taking the items from the package, check that all items shown below are provided.  
If any item is missing or damaged, contact Evident .

Checkbox


- Motorized XY stage  
DSX20-RMTS/DSX20-LMTS/DSX20-TMTS




- Stage plate




- Black-and-white plate  
(DSX20-RMTS/DSX20-LMTS only)



- High-precision plate



- Black-and-white plate  
(DSX20-TMTS only)




- Rubber caps (4 pcs.)



- Allen wrench



- Flathead screwdriver




# DSX20-RMTS/DSX20-LMTS/DSX20-TMTS 同梱品一覧


梱包箱から同梱品を取り出しましたら、不足しているものがないかご確認ください。  
万一、同梱品が不足していたり、破損している場合は、エビデントの販売店にご連絡ください。

## チェック欄


- 電動 XY ステージ本体  
DSX20-RMTS/DSX20-LMTS/DSX20-TMTS




- ステージプレート




- 白黒プレート  
(DSX20-RMTS/DSX20-LMTS のみ )



- 高精度プレート



- ガラスプレート (DSX20-TMTS のみ )



- ゴム栓 (4個)



- 六角レンチ



- マイナスドライバー

