



**CTRL+A:** Set A-scan resynchronization gate  
**CTRL+SHIFT+A:** Resynchronize A-scan  
**CTRL+E:** Reset envelope mode  
**CTRL+SHIFT+E:** Toggle the envelope mode  
**CTRL+F:** Freeze live A-scan mode  
**CTRL+SHIFT+H:** Hide menu and toolbars  
**CTRL+O:** Open a file  
**CTRL+N:** Load default configuration  
**CTRL+M:** Maximize/Minimize view  
**CTRL+Delete:** Delete view  
**CTRL+SHIFT+Delete:** Empty view  
**CTRL+1, 2, 3... 0:** Display layout  
**CTRL+I:** Open OmniScan file  
**CTRL+S:** Save configuration as  
**CTRL+Drag:** Draw contour

**ALT+C:** Automatic volumetric merge by group  
**ALT+V:** Automatic volumetric merge  
**ALT+ENTER:** View properties

**SHIFT+ENTER:** Open view **Contents** dialog box

**CTRL+Drag cursor:** Move 2 cursors together  
**CTRL+Drag gate selectors:** Move 2 gate selectors together  
**CTRL+Click zoom bar:** Edit zoom bar start and end values  
**CTRL+SHIFT cursor:** Move cursor label

**Delete:** Delete active note  
**Page Up:** Move gate selectors to next position  
**Page Down:** Move gate selectors to previous position

**SHIFT+F4:** Apply view preference  
**CTRL+F8:** Change group

## Move Cursors

### Arrow keys:

Move reference (red) cursor: Up, Down, Left, Right

### SHIFT+arrow keys:

Move measurement (blue) cursor: Up, Down, Left, Right